








## How To Install: McCoy Kicker System



**SECURE your STARTER BARS to stabilize the system.**

**1m** centre spacing per bracket

**1** **3** strong ties along the brace



**1 SECURE your STARTER BARS to stabilize the system.**

tie the bracket to the rebar at your required slab height

2 Loosen thumb screws & slide the wire chair to align bracket to correct width of concrete upstand

Lock wire chair alignment by hand tightening the thumb screws then finish with a half turn on your nips

**3 Set timbers onto wire chair**

4 Tie a 'loop tie' with the tying wire to pressurise the timber into the bracket

5 You have clear access to pour & poker concrete in preparation for waterproofing systems


6 Cut tying wire to release timbers. Please clean and stack the timbers for re-use.

7 A quality monolithic concrete upstand is formed



J G McCoy

## How To Install: The Loop Tie



4 A

4A Loop the tying wire around the 5mm wire of the Kicker Bracket. Tying wire pressurises timber into the Kicker Bracket, which secures the whole system